

PLAQUE ATHANOR - CLEANING -

/!\ Warning :



- **NEVER POUR ICE OR COLD WATER WHEN THE PLAQUE IS STILL HOT**



To speed up the cooling of the plaque Athanor :

4. Put the plaque in position 0,
5. Place a pot of cold water that covers the surface of the steel plate,
6. The plaque reaches 180°C in 10 minutes.

After each service do the following process.

Cleaning a Plaque Athanor last between 4 to 5 minutes.

Our advice is to use the hot plate degreaser « EMULPLAC 180°C – THOMIL ».

At the end of service, must wait that the plaque will be under 180°C.

The canopy must be switched on.



Put cleaning product on plaque and spread it with a spatula. Let act 30s.

Rinse and remove the rests with spatula



If the plaque is still dirty, redo the last stage.

Rinse a lot.

Spend a wet and clean dishcloth



Do the same on each edge, the plaque will be as new.

Do not forget to empty and cleaning the drawer



ATHANOR

Tel : +33 (0)4 76 93 03 26 | www.athanor-fourneaux.fr

For all service enquires : sav@athanor-fourneaux.fr